

aHardware Installation Guide


The Operations Team must follow the steps below

PRE-INSTALLATION:

1. Technical Reconnaissance (scope site layout & choose cabinet locations)
2. Plan the project (time-line, project lead, components needed, etc)
3. Start a hardware requisition
4. Order materials/components
5. Reconcile procurement of materials with project needs
6. Modify exiting hardware:
 - Add holes for fans & wires
 - Add block board to all cabinets covering the entire interior back wall of the cabinet

HOW TO CHOOSE CABINET LOCATIONS:

1. Pick a central location for the Switchboard:
 - Distance between cabinet & workstations **should not be** > 100m
 - If distance between any 2 points exceed 100m = add another switchboard cabinet




2. Choose a central location for the Server Cabinet:
 - Needs to be in a well ventilated room, at least 1 window
 - Room needs to be secure: windows with bars and door with locks
3. Choose a well ventilated area for the Power cabinet:
 - Location should be close to ECSOM distribution board & safe from theft and weather conditions
 - For J2's, if greater than 10 workstations = + 1 Power Cabinet (a full back up system with 4 batteries)

CABINET DESIGNS:


Standard Design = 3 cabinets. Switchboard + Server + Power


Alternative Design = 2 cabinets. (Switchboard + Server) + Power

CABINET LAYOUT



Correct


NOT



Incorrect


STANDARD DESIGN

All cabinets in different rooms: see below



ALTERNATIVE DESIGN

Server & Switchboard in the same cabinet stacked vertically on top of the Power Cabinet: see below



DAY OF INSTALLATION

Should be done prior to Back Data Entry by Support & Deployment Team

Alternative Back Data Entry: The Support & Deployment Team connects touch-screens to a local server and ESCOM electricity, with a working hospital generator or Baobab generator, then migrate data later.

PRIOR TO DEPARTURE:

Use the "Hardware Check-list" to confirm you have all materials needed to bring to the site.

DAY 1: RUN WIRES & PIPES

1. Install PVC pipe for power connections (power cables for 48 volts inside)
2. Install PVC trunking (plastic covering) for Ethernet cables (connected to data socket)
3. Terminate Ethernet cables
4. Install data sockets (run cables to switchboard)

DAY 2: INSTALL CABINETS

1. Install Server cabinet
2. Install Switchboard cabinet
3. Install Power back up cabinet

DAY 3: TEST

1. Test Connectivity- use a laptop to test Ethernet connection to the site server (i.e. "ping" server IP addresses). Test point of care at each ward. Unsuccessful response = "host unreachable"
2. Test Power Connections with volt multimeter to make sure 48 volts are coming from each power socket that is connected to the four batteries in the power cabinet.
3. Install a data cable link (covered with PVC trunking) from the Baobab system to the HMIS system (i.e. their switchboard or computer in the HMIS office if the site does not have a network)
4. Test connectivity between Baobab system & HMIS office (i.e. "ping" server IP address)
5. If site has internet, configure Baobab server on site to access Baobab HQ server ("Cottonwood")

SECURITY & SAFETY: FINAL CHECK

1. All cabinets must have a padlock
2. All rooms must be locked
3. Label keys: 1 set of with HMIS Officer & 1 set at Baobab HQ in Operations Department key cabinet
4. Every room with a power cabinet needs to have a fire extinguisher

Should not take more than 1 business week (5 days)

ENTER SUPPORT & DEPLOYMENT TEAM

Install Touch-screens
Run & Test Baobab module

OPERATIONS HARDWARE CHECKLIST

CHECK LIST FOR NEW SITE HW INSTALLATION

TOOLS/ MATERIALS REQUIRED

QTY
CHECK

Keys for server room & cabinets
 110V AC Transformer
 2.5mm earth wire
 48V cooling fan
 Babble level
 Bag of cement
 Batteries
 Battery Charger
 Battery charger for drill machine
 Battery terminals
 Blockboard
 Builder's knife
 Circuit Breaker
 Computer server
 Draw wire
 Drill bits (concrete, steel, wood bits)
 Drill machines (both electric & battery power)
 Electric hacksaw
 File
 Fish tape
 Hacksaw
 Hammer
 Hydraulic cutting machine
 Insulation tape
 Key for drill chunk
 Ladders
 LVD
 Multimeter
 Network Switch
 Padlocks for cabinets
 Plain bend
 Pliers
 Power Extension cord
 PVC coupling
 PVC Nipples
 PVC pipes (25mm,110mm,20mm)
 PVC pipes (25mm,110mm,20mm)
 PVC saddles
 PVC trunking
 RJ45 connectors
 RJ45 Crimping tool
 Router if necessary
 Screw drivers
 Screws, Nut & bolts
 Side Cutters
 Soldering station, Solder wire
 SW Mounting Bracket
 Spanners
 Speakon connectors
 Spring bender
 Surge protector
 Tape measure
 Torch
 Twin surface switch
 USB-Serial adapter
 Voltage monitor
 Water pipe
 Work Suit